

RVZ5000000

Concrete cutter



SPARE PARTS CATALOGUE

SPARE PARTS ORDER

Firma / Company:

.....

Address:

Country:

Contact person:

Tel.:

Fax:

e-mail:

Delivery: ☐ express

☐ stock

Shipping mode:


Seriál Number	Part Number	Part Name	Quantity	Comment

Datum / Date:

Signature:


Part Name:
CONCRETE CUTTER

Drawing number RZ120 -
20383A, 20391A, 20394A RZ170 -
20376A, 20392A, 20395A RZ200 -
20364A, 20393A, 20396A



POZ.	NAME
1	FRAME
2	DRIVE
3	UNDERCARRIAGE
5	CONTROL
6	COOLING
7	BELT COVER
8	ACCESORIES

Machine Type: RZ120, RZ120B, RZ120S, RZ170, RZ170B, RZ170S, RZ200, RZ200B, RZ200S




SPARE PARTS CATALOGUE

Part Name: FRAME WITH HANDLEBARS 20371A				
Position	Part Number	Part Name	Piesed used	Hmotnost/Weight
1	20372A	FRAME	1	
2	31988A	FRONT COVER	1	
3	31980A	HANDLEBARS	1	
4	42318A	BRAKE PADS	1	
6	2125000084	WASHER	3	
7	2934000008	NUT	2	
8	2738008020	BOLT	2	
11	2933008020	BOLT	1	
13	4260000211	BOLT	1	
14	2931010080	BOLT	1	
15	42281A	HOLDER	2	
16	2738010020	BOLT	2	
17	4200785018	TENSIONER	2	
19	42284A	SWITCH BRACKET	1	
22	31260713906	SWITCH	1	
23	4260000212	BOLT	2	
24	4014014013	HANDLE	2	
Machine Type: RZ120, RZ170, RZ200				

SPARE PARTS CATALOGUE

Název / Part Name: FRAME WITH HANDLEBARS 20371A				
Position	Part Number	Part Name	Pieces used	Hmotnost/Weight
29	2934000010	NUT	1	
30	2798000010	WASHER	1	
31	42351A	COVER SHEET	1	
34	2798129095	BOLT	2	
35	42284A	SWITCH HOLDER	1	
36	6000000296	HOUR COUNTER	1	
Machine Type: RZ120, RZ170, RZ200				



SPARE PARTS CATALOGUE


Part Name: FRAME WITH HANDLEBARS 20414A			
Position	Part Number	Part Name	Piesed used
1	20372A	FRAME	1
2	31988A	FRONT COVER	1
3	31980A	HANDLEBARS	1
4	42318A	BRAKE PADS	1
6	2125000084	WASHER	3
7	2934000008	NUT	2
8	2738008020	BOLT	2
11	2933008020	BOLT	1
13	4260000211	BOLT	1
14	2931010080	BOLT	1
15	42281A	TENSIONER HOLDER	2
16	2738010020	BOLT	2
17	4200785018	TENSIONER	2
19	42284A	SWITCH BRACKET	1
22	6000000035	SWITCH	1
23	4260000212	BOLT	2
24	4014014013	HANDLE	2
Machine Type: RZ120B, RZ120S, RZ170, RZ170B, RZ170S, RZ200, RZ200B, RZ200S			

SPARE PARTS CATALOGUE

Part Name: FRAME WITH HANDLEBARS20414A			
Position	Part Number	Part Name	Piesed used
29	2934000010	NUT	1
30	2798000010	WASHER	1
31	42352A	COVER SHEET	1
34	2733724100	RIVET	4
36	6000000296	HOUR COUNTER	1
Machine Type: RZ120B, RZ120S, RZ170, RZ170B, RZ170S, RZ200, RZ200B, RZ200S			

Part Name:
DRIVE

Drawing number **RZ120 -**
20378A RZ170 - 20377A
RZ200 - 20379A



KATALOG NÁHRADNÍCH DÍLŮ / SPARE PARTS CATALOGUE

Part Name:		20377A, 20378A, 20379A 20398A, 20399A, 20400A 20401A, 20402A, 20403A	
DRIVE			
Position	Part Number	Part Name	Pieces used
1	3120010032	ENGINE	1
	3120010111		
	3120010106		
	3120010053	ENGINE	
	3120010112		
	3120010105		
	3120010053	ENGINE	1
	3120010112		
	3120010105		
2	42086A	PULLEY	
	40162E		1
	42144A		
3	31735A	BLADESHAFT	1
4	41902A	PULLEY	1
5	3110000208	BEARING	2
6	31658A	DISC FLANGE I	1
8	42026A	DISC FLANGE II	1
9	2125000170	WASHER	8
10	2934000016	NUT	4
11	2933016045	BOLT	4
12	2912006016/2	BOLT	4
13	2256288750	KAY	1
14	2256286625	KAY	1
15	42093A	THREADED BAR	2
16	2912010040	BOLT	4
17	2125000105	WASHER	4
18	42028A	DISC NUT	1
19	32123A	BLADEGUARD	1
20	41167A	ARM	1
21	4260000212	BOLT	1
Machine Type: RZ120, RZ120B, RZ120S, RZ170, RZ170B, RZ170S, RZ200, RZ200B, RZ200S			


SPARE PARTS CATALOGUE

Part Name:			20377A, 20378A, 20379A 20398A, 20399A, 20400A 20401A, 20402A, 20403A	
DRIVE				
Position	Part Number	Part Name	Piesed used	
22	2316012030	BOLT	1	
23	408000900 408000850 41061A	BELT	3	RZ170+B+S RZ200+B+S RZ120+B+S HONDA
24		EXHAUST DEFLEKTOR	1	
25	2798504006	BOLT	2	
27	600042374A	APERTURE	1	
28	2985000006	NUT	1	
29	2933006016	BOLT	1	
30	2902100006	WASHER	1	
31	2125000064	WASHER	1	
32	40172A	WASHER	1	
33	2933008025	BOLT	1	
34	2798000010	WASHER	5	
36	2125000105	WASHER	1	
Machine Type: RZ120,RZ120B, RZ120S, RZ170, RZ170B, RZ170S, RZ200, RZ200B, RZ200S				

Part Name:

Drawing number **31971A**

UNDERCARRIAGE




SPARE PARTS CATALOGUE

Part Name:			Čís. výkr.
UNDERCARRIAGE			31971A
Position	Part Number	Part Name	Piesed used
1	20372A	UNDERCARRIAG	1
2	30073B	HINTERRAD	2
3	30073C	FRONT WHEEL	2
4	2792010020	BOLT	4
5	2125000105	WASHER	4
6	2125000084	BEARING	2
7	2125000130	WASHER	8
8	2934000012	NUT	4
9	2933012035	BOLT	4
10	2934000008	NUT	2
11	2738008020	BOLT	2
12	42283A	INDICATOR	1
Machine Type: RZ120, RZ120B, RZ120S, RZ170, RZ170B, RZ170S, RZ200, RZ200B, RZ200S			

Part Name:
CONTROL

Drawing
31998A

number




SPARE PARTS CATALOGUE

Part Name: CONTROL 31998A			
Position	Part Number	Part Name	Piesed used
1	42103S	PAKA OVLADANI LEVER CONTROL HEBELSTEUERUNG	1
2	4260004010	HEADS	1
3	4014085038	STOPPER	1
4	21912010080	BOLT	1
5	42120A	HOUSING	1
6	42121A	CONTROL SCREW	1
7	42106A	CONTROL TUBE	1
8	2934000012	LUBRICATORS	1
9	2934000010	NUT	5
10	2220000002	PIVOT	1
11	3110000207	BEARING	1
12	2931010060	BOLT	1
13	2738010045	BOLT	4
14	2125000105	WASHER	6
15	31987A	SUSPENSION	1
Machine Type: RZ120, RZ120B, RZ120S, RZ170, RZ170B, RZ170S, RZ200, RZ200B, RZ200S			

Part Name:
COOLING

Drawing
32000A

number




SPARE PARTS CATALOGUE

Part Name:				
COOLING			32000A	
Position	Part Number	Part Name	Piesed used	Hmotnost/Weight
1	600032027A	WATER TANK	1	
2	600031858A	PLUG	1	
3		FAST COUPLING	1	
4	3815232503	COUPLING PIECE	1	
5	4016001400	HOSE L=500mm	1	
6	4014435001	VALVE	1	
7	4016001400	HOSE L=80mm	1	
8	4014014011	CONNECTING THROAT	1	
9	4016001400	HOSE L=310mm	2	
10	40213AA	NOZZLE	2	
11	3651002015	CLIP	2	
12	2933006012	BOLT	2	
13	2985000006	NUT	2	
99	32039A	DISTRIBUTION OF WATER - SET - POS. 4-13	1	
Machine Type: RZ120, RZ120B, RZ120S, RZ170, RZ170B, RZ170S, RZ200, RZ200B, RZ200S				

Part Name:
BELT COVER

Drawing number **32026A**




SPARE PARTS CATALOGUE

[illegible]

Part Name:
ACCESORIES

Drawing number **32042A**



SPARE PARTS CATALOGUE

[illegible]